

## KEMFLOR 525

### EPOXY SCREED FLOOR COATING

Rev.00-241110

#### PRODUCT DESCRIPTION

Solvent less epoxy floor topping for heavy industrial use .It enhances the total system's quality.

- Enhance total system finish
- Solvent - free
- No fire risk
- Very high mechanical strength
- Excellent adhesion to substrate
- Easy & fast application

#### INTENDED USES

Some typical applications include:

- Food and drink processing plants
- Pharmaceutical and cosmetic plants
- Hospital exhibition, storage, clean room
- Laboratory etc.

#### SPECIFICATION DATA

<b>Thickness</b>	1 mm
<b>Type</b>	3 pack
<b>Shade</b>	N/A
<b>Finish</b>	N/A
<b>Chemical Base</b>	SL Epoxy Polyamide Screed
<b>Mixing Ratio</b>	5:2:10/wt
<b>Coverage kg/sq.m.</b>	1.84
<b>Recommended No. Of Coats</b>	1
<b>Re-coating Interval</b>	Min. 16 hrs
<b>Surface Dry Time</b>	4 hrs
<b>Curing Time</b>	7 days
<b>Pot Life</b>	30 min.
<b>Shelf Life (under std. condition)</b>	12 months
<b>Recommended System</b>	Primer + Screed
<b>Pack Size</b>	68 kg

**Note:** These figures are theoretical under controlled conditions and may vary depending upon site conditions i.e. temp., humidity, surface porosity, surface profile, handling of material etc.

## KEMFLOR 525

### EPOXY SCREED FLOOR COATING

Rev.00-241110

#### DIRECTION OF USE

##### **SURFACE PREPARATION:**

As is the case with every coating scheme, the surface profile is of utmost importance. In order to achieve optimum bonding between substrate and coating, it is necessary to apply product only on fully dry and neatly cleaned surfaces.

##### **Precautionary measures for new concrete floors:**

Newly laid concrete surfaces are; For the first month or so after pouring, "green" meaning i.e. wet and alkaline. New concrete should be allowed to cure for 28 days prior to coating because of the concerns over the effect of water on floor coating adhesion. Check the moisture level (should be below 5%) prior to application.

##### **Precautionary measures for old concrete floors:**

Surface should be free from dust, grease, oil, laitance, loose material, old coatings etc. Generally cleaning with Kleenol or equivalent is enough to remove grease/oil. Smooth, aged concrete may be etched with dilute hydrochloric acid for suitable roughness and better adhesion of the epoxy flooring. In case of heavy oil & grease contamination, existing partial coating or structurally unsound concrete layer has occurred or old coatings are present mechanical cleaning is advisable.

##### **KEMFLOR 525 APPLICATION:**

After surface preparation depending upon the system adopted KemFlor 525 can be applied on primer. Add the KemFlor 525 parts, under continuous stirring by a very slow speed electric stirrer, till the mixture is homogeneous. DO NOT MIX BY HAND. Remove all material from each can. Scrape the sides of the container several times to ensure complete mixing. Be careful to not introduce any air bubbles while mixing.

Since the mix ratio is critical to the performance of the flooring system, Quantity to be mixed should be calculated beforehand based on the area to be covered and coating thickness desired. Actual coverage will depend on texture, porosity, slope of the substrate.

Pour the mixed KemFlor 525 onto the surface as soon as possible (See pot life) and spread using a notched trowel. Immediately after the trowel application, a spiked roller should be used to ensure a level homogenous surface free of voids and surface imperfections.

Do not overwork the material. Apply slowly to minimize bubbling. If bubbles appear, use a porcupine roller to produce a bubble free film.

#### CLEAN UP

For cleaning of application equipment and tools use Chembond's thinner no.3.



#### **Chembond Chemicals Limited**

Chembond Centre  
EL-71, MIDC Mahape,  
Navi Mumbai 400 710  
INDIA

Tel: (91 22) 66143000 / 315  
Fax: (91 22) 768 1294  
E-mail: sales@chembondcoatings.com  
Website: www.chembondindia.com

## KEMFLOR 525

### EPOXY SCREED FLOOR COATING

Rev.00-241110

MAINTENANCE	SAFETY PRECATIONS
<p>For maximum life expectancy, routinely sweep and wash floors with conventional detergent cleaners. Do not steam clean: all spills powder or liquid should be cleaned up immediately. Inspect the floor regularly for wear, breaks or damages, if found any immediately consult with Chembond's technical service personnel or authorized applicator.</p>	<p>Take care to avoid skin or eye contact and breathing vapours. In the event of the skin contact immediately wash thoroughly. In the event of eye contact, wash continuously for 15 minutes in water and seek medical advice. Wear protective clothing, gloves, and safety glasses while using this product. If inhalation occurs, move to fresh air and seek medical advice in case of difficulty in breathing. Keep material away from heat, flames, and sources of ignition. For further details read Material Safety Data Sheet.</p>
LIMITATIONS OF LIABILITY	
<p>This information is based on our current level of knowledge. It is given in a good faith but it is not intended to guarantee any particular properties. The users must satisfy themselves that there are no circumstances requiring additional information or precautions or the verification of details given herein.</p>	



#### Chembond Chemicals Limited

Chembond Centre  
 EL-71, MIDC Mahape,  
 Navi Mumbai 400 710  
 INDIA

Tel: (91 22) 66143000 / 315  
 Fax: (91 22) 768 1294  
 E-mail: sales@chembondcoatings.com  
 Website: www.chembondindia.com